

ALARM INSTALLATION SPECIFICATION Mod. 7056 / 7057



VEHICLE: SUBARU LEGACY and OUTBACK - Year of registration 2007

SPECIFICATION Nr.: 42-8 / BLK

LOCATION

Compact alarms and sirens
Control units and modules

- ⇒ On the passenger side chock absorber support.
- ⇒ Under the driver side dashboard.

RUNNING OF ALARM WIRING

- ⇒ Use the passenger side original grommit, near the shock absorber support.

SUPPLY

Positive

- ⇒ 6 mm2 RED wire, 10-way brown connector connected at the back of the fuse box, placed under the driver side dashboard.

Negative

- ⇒ To a bolt of the metallic frame.

FUNCTION AND CONNECTION PROCEDURE	WIRE COLOUR OF THE VEHICLE	WIRE POSITION
TURN SIGNALS: 	BLUE-YELLOW 0,75 mm2 RED-YELLOW 0,75 mm2	<u>Connector:</u> WHITE 8-way connected to the turn signals control unit, fixed over the relay bracket placed on the fuse box right side.
POSITIVE UNDER KEY: 	GREEN 4 mm2	<u>Connector:</u> BROWN 10-way connected at the back of the fuse box.
1ST ENGINE IMMOBILISER: (starter motor).  Use a 30 Amp. Relay Gemini 2352GE.	WHITE 4 mm2	<u>Connector:</u> BROWN 10-way connected at the back of the fuse box.
2ND ENGINE IMMOBILISER: (fuel pump – gasoline vehicles).  Use a 30 Amp. Relay Gemini 2352GE.	RED-BLACK 2,5 mm2	<u>Connector:</u> WHITE 16-way fixed at the back of the driver side kick-plate.
ELECTRICAL WINDOW WINDER: use a Gemini 2343 module. 	<u>Front:</u> a. + ↑ LH: BLUE-RED b. + ↑ RH: RED <u>Rear:</u> c. + ↑ LH: GREEN-RED d. + ↑ RH: BLUE All sized 1 mm2 and with GREY ref..	a. <u>Connector:</u> GREY 2-way connected to the window winder motor, inside the driver side door. b. c. d. <u>Connector:</u> WHITE 26-way fixed at the back of the driver side kick-plate.
DOORS AND BOOT SWITCHES: 	BLACK-RED ref. GREY 0,75 mm2	<u>Connector:</u> WHITE 16-way fixed at the passenger side wind screen pillar base.
BONNET SWITCH: install the supplied push button over the passenger side headlight, near the bonnet rubber rabbet.		
CONNECTION OF DOOR LOCKING MOTOR (suggested): 	YELLOW-BLUE GREEN-BLUE	<u>Connector:</u> WHITE 26-way fixed at the back of the driver side kick-plate.
	YELLOW-GREEN 0,75 mm2 RED-GREEN 0,75 mm2	

NOTE: It is suggested to exclude the current absorption sensor.

IMPORTANT: ALL INFORMATION INCLUDED IN THESE SPECIFICATIONS ARE MERELY INDICATIVE AND NOT RESTRICTIVE.